

Panasonic DBS576/HD to KX-TVS 50 Integration

DBS576/576HD Programming

Enter programming mode from a 12, 22 or a 34 key display phone:

- 1) Press ON/Off key
- 2) Press Program Key Dial ** and enter password

Assign voice mail extension numbers:

- 1) Press FF3 Key
- 2) Dial 0, enter port number dial 02, press Hold
- 3) Enter the ext number
- 4) Press block down to go to the next voice mail port
- 5) Repeat steps 3 and 4 for all voice mail ports

Assign Voice Mail Parameters:

- 1) Press FF3 Key
- 2) Dial 0, enter the first port number, dial 0406, press Hold, dial 1
- 3) Press Block Down to the next voice mail port, dial 1
- 4) Repeat step 3 for all voice mail ports

Assigning positive disconnect for the voice mail ports:

- 1) Press FF3 key
- 2) Dial 0, enter the first voice mail port number, dial 04 20, press Hold, dial 1
- 3) Press Block Down to the next voice mail port, dial 1
- 4) Repeat steps 3 and 4 for all voice mail ports

Assign COS 15 for voice mail ports

- 1) Press FF3 key
- 2) Dial 0, enter the first voice mail port number, 07, press Hold, dial 15
- 3) Press Block Down to the next voice mail port, dial 15
- 4) Repeat step 3 for all voice mail ports

Assign voice mail extensions to a hunt group

- 1) Press FF5 key
- 2) Dial 1 01 hold set Hunt Type to 4
- 3) Press FF5 key
- 4) Dial 1, enter the hunt group number, dial 02, press the Hold key, dial the pilot number, press the Hold key
- 5) Dial the first voice mail extension number, press the Hold key
- 6) Dial the next voice mail extension number, press the Hold key
- 7) Repeat step 4 for all voice mail extensions

Assign call forward no answer to extensions covered by voice mail:

- 1) Press FF8 key
- 2) Dial 1, 09, 1 press hold
- 3) Dial the ext number to be forwarded, press Hold, dial the pilot number of the voice mail hunt group, press hold
- 4) Repeat step 3 for all extensions that are covered by voice mail.

Assign optional call forward busy to extensions covered by voice mail:

- 1) Press FF8 key
- 2) Dial 1, 09, 0, press hold
- 3) Dial the ext number to be forwarded, press Hold, dial the pilot number of the voice mail hunt group, press hold
- 4) Repeat step 3 for all extensions that are covered by voice mail.

Assign call forward ID codes for the phones covered by voice mail:

- 1) Press FF8 key
- 2) Dial 1, 05, press hold twice
- 3) Dial the extension number covered by the voice mail, press hold, dial #6, dial the ext covered by voice mail, press hold
- 4) Repeat step 3 for all extensions that are covered by voice mail.

Assigning message ID codes for phones covered by voice mail:

- 1) Press FF8 key
- 2) Dial 1, 05, press Hold twice
- 3) Dial the extension number covered by voice mail, press hold, dial *, the ext number, press hold
- 4) Repeat steps 3 for all extensions covered by voice mail

Assigning voice mail transfer key number 2 parameters:

- 1) Press FF1 key
- 2) Dial 0, 24, 0003, press hold
- 3) Dial #6, press hold

Assigning voice mail transfer key number 2 to phones:

- 1) Press FF4 key, dial 0, enter the port number to be programmed, dial 0 plus the two digit key number to program, press hold.
- 2) Dial 75, enter the pilot number of the voice mail hunt group
- 3) Press Block Down to the next port to have the voice mail transfer key
- 4) Repeat step 2 and 3 for all phones that need a voice mail transfer key

Assigning voice mail access keys to phones:

- 1) Press FF4 key
- 2) Dial 0, the port number to be programmed 0 two digit key number to be programmed 76 and the voice mail pilot number

Or

- 1) Press FF8 key
- 2) Dial 1, 01, Hold three times, dial the extension to be programmed, press hold, dial the speed dial button to assign the key to, press hold, dial *, enter the extension number, press hold.
- 3) Repeat for all extensions that need a voice mail access key

TVS Programming (Make sure Hyper Terminal is set to VT-100 emulation)

Assigning preliminary voice mail programming:

- 1) Enter Quick Setup
- 2) Select PBX Type as Other
- 3) Assign Mailboxes
- 4) Assign Auto Attendant Type for all ports
- 5) Assign passwords
- 6) Set the Time and Date

Assigning direct access to mailboxes:

- 1) Enter Program mode
- 2) Enter Service Settings
- 3) Enter Custom Service
- 4) Enter the Custom Service number for day greeting
- 5) Use the enter key to get down to key pad assignments for the *, and set it to I subscriber service
- 6) Exit to Program Menu

Assigning message waiting lamp port:

- 1) Enter the System Parameter Settings
- 2) Enter Others
- 3) Enter Message Waiting Delivery
- 4) Restrict message waiting delivery to the voice mail last port only
- 5) Exit to the Program Menu

Assigning Disconnect and Flash timing:

- 1) Enter Hardware Settings
- 2) Enter Port Settings
- 3) Set each port for flash time of 600ms
- 4) Set each port for CPC signal of 450ms
- 5) Repeat for all ports
- 6) Exit to Hardware Settings Menu

Assigning PBX Parameters

- 1) Enter PBX Interface Parameters
- 2) Set PBX Type to other
- 3) Set Operator Transfer to FXD
- 4) Set Extension Transfer to FXD
- 5) Set Alternate Extension Transfer to FXD
- 6) Set Light On to W*41X
- 7) Set Light Off to W*49X
- 8) Exit to Hardware Settings

Assigning Inband Signaling:

- 1) Set Inband Signaling Type to none
- 2) Exit programming